

Problem work-out manual for Children ride on car

No.	Problem	Check parts	check steps	work-out	Remark
1	It doesn't move	1.1 Pedal switch	①checking if wire and pedal switch are in good connection	it should be red, brown, black wire from the front	or white, grey, black
			②checking if power goes through or not	change new switch	
		1.2 main switch	①checking main switch and wire	fix wire with switch	
			②checking wire and terminal	fix terminal	
			③check if short-cut or no power	change new switch	
		1.3 fuse	①open seat and check if fuse is burnt	Change fuse	For CT-8xx, please open hook
		1.4 Battery	①checking if wire is falling off	connect wire with battery	
			②checking voltage. it should be over 5.5V	charging battery for over 8 hours. If it is not working, please change new battery	
			③Checking if battery is idle too long without charging		
		1.5 motor	①checking wire connected to motor	fix wire with motor	
②checking if motor is burnt	change new motor				
2	No hi-speed	2.1 fuse	①checking if one of fuse is burnt	change new fuse	for any two motor cars
		2.2 Battery	①checking if one of battery wire is off	fix the wire	
			②checking if one of battery is damaged	change new battery	
		2.3 Main switch	①checking wire holder with main switch	fix the wire holder	
②checking wire with main switch	fix the wire				
3	starting the car, then fuse burnt or short-cut	3.1 motor	①checking if motor burnt or not	change new motor	
		3.2 gearbox	① checking if any sound comes out from gearbox	change new gearbox	
		3.3 rider	① if the rider is overweight	please follow weight limit	
		3.4playground	① if you ever rider the car in grass or sand area	suggest to ride the car in smooth area	
4	No music	4.1 battery	①checking AA battery	change new battery	
		4.2 wire	①check musical IC with wire and terminal	fix the wire and terminal	
5	it doesn't move while remote	5.1 remot switch	①check remote switch is on	switch it on	
		5.2 motor	①check wire connected to motor	fix wire	
			②check if motor is good	change motor	
		5.3 remote controller	①check battery in remote control	change new battery	
			②check chips connected to battery	clean the chips	
		5.4 remote circuit	①checking connection wire	fix wire	
②checking receptor	change receptor				
6	Missing parts	6.1 parts list	①checking parts position by provided parts list	contact sales department for parts replacement	
		6.2instrucion sheet	②assembly car in accordance with instruction sheet		
		6.3 Carton	③checking if PE bag if sealed, or carton is broken		